

Powerboat Basics

How to Start

1. Load fuel tank, connect fuel hose and pump fuel line primer bulb until firm.
2. Turn battery switch to “ON” (located by the battery only). Only applicable for WSC1
3. Lower motor fully (using the thumb control on the shift lever)
4. Turn key to “ON” position
5. Lift choke/fast idle lever fully (located below the shift lever)
6. Turn key to start position. Crank 5 seconds and wait 10 seconds to repeat
7. After engine starts, run at fast idle for a moment until it warms up
8. Return choke to “OFF” position
9. Remove bowline, shift to reverse and gently power off the boat ramp

Remember life jackets for all on board. Children must wear a life jacket at all times

Stopping

1. Power onto the boathouse ramp slowly
2. Secure bowline
3. Turn off engine
4. Raise engine
5. Turn battery master switch to “OFF” position. Only applicable for WSC1
6. Turn radio off
7. Disconnect fuel and return to locker
8. Report any problems or maintenance needs to Dee Lockwood, 503-639-9189

Help extend the life of the powertrain...don't be a frequent shifter!

